





## Technical Specifications

Quality	<b>RTR HPS - "Hot Peel Strong"</b>		
Main Characteristics	For strong colour supports.	Presentation (Support)	Paper or transparent film.
Graphic Quality	High detail printing.	Dimensions	Width (mm): 10 up to 130 Length (mm): 10 up to 250
Colours	Reproduction to PANTONE® colours.		
Indicated Bases	Cotton, Polyamide, Polyester, no coated materials.		
Washing Instructions			

## Recommendations

Recommended Use	<ul style="list-style-type: none"> <li>• Underwear</li> <li>• Sportswear</li> </ul>	<ul style="list-style-type: none"> <li>• Bath and swimming</li> <li>• Baby strollers</li> </ul>	<ul style="list-style-type: none"> <li>• Shoes and insoles</li> <li>• T-shirts, etc.</li> </ul>
Application Conditions	<ul style="list-style-type: none"> <li>• Temperature: 170-200°C</li> <li>• Time: 1-5 sec.</li> <li>• Pressure: 2-3 Bar</li> <li>• The transfer reaches its maximal resistance 36 hours after its application.</li> </ul>		
Storage	<ul style="list-style-type: none"> <li>• Stock in a dry place, without dust and preferably with controlled temperature.</li> <li>• Do not expose to direct solar light or other heat sources.</li> <li>• Do not stack with weight.</li> <li>• In normal conditions recommended durability to apply a transfer is one year from its production.</li> </ul>		
Tests	<ul style="list-style-type: none"> <li>• It is recommended to perform tests over the materials to be used.</li> <li>• HELIOTEXTIL is available to perform tests.</li> </ul>		
Responsibility	<ul style="list-style-type: none"> <li>• HELIOTEXTIL recommends application conditions and will not take any responsibility for the transfer application by the client.</li> <li>• HELIOTEXTIL assumes that before formulating the order and before using the products, the client validated the requirements of intended end use.</li> </ul>		
Presentation	<ul style="list-style-type: none"> <li>• Rolls</li> </ul>		

## Application Sequency



1. Follow the recommended application conditions and regulate the placement of the transfer on the piece.  
Initiate the continuous application, placing the piece on the press.
2. Remove the piece from the press and continue the application.